



Contact us We are here to help, feel free to contact us with questions or to provide feedback. For additional information, please visit the FAQ section of our website at www.distributel.ca. To provide feedback, please submit a customer review via our website or our Facebook page. For other questions, please call our Customer Experience team at 1-877-810-2877. You can also receive Technical Support at the same number, or send an email to technical.support@distributel.ca.

High Speed I Setup Guide








High Speed DSL Internet

Thank You for choosing Distributel

In order to ensure the smooth setup of your Distributel High Speed DSL Internet service, please follow the easy steps laid out in this guide.




The setup kit for your High Speed DSL service should contain the following items:



*Please note that the modem shown is for the purposes of illustrating the setup process and may differ from your device.

Before beginning the setup process, please ensure that all of your equipment is turned off.


For customers with a landline phone, your setup kit will also include a splitter and filter. Please follow special instructions in Step 1 and Step 4.



STEP 1


Using the phone cable provided in your installation kit, connect the grey DSL port located on the back of the modem SR505N to your phone jack.

For customers with a landline phone, connect the grey DSL port located on the back of the modem to the DSL port of the splitter. Then connect the splitter to your phone jack.




Back of Modem SR505N

STEP 2 Using the Ethernet cab laptop (or the WAN po




You



Front of Modem SR505N

STEP 4 c

For customers with a landline phone, the filter(s) must be connected between your phones and their corresponding phone jacks, as illustrated below.



Phone Jack

Using the Ethernet cable provided, connect the modem SR505N LAN port to your laptop (or the WAN port of your router if you would like a network setup).

You may now turn all your devices back on.

STEP 3

Please wait 2 minutes for the modem to boot-up. The POWER and DSL lights should become solid green. The INTERNET and the LAN1 lights should become solid or blinking green. If you do not see the mentioned lights, please repeat steps 1 and 2. Ensure that the switch button, located in the back of the modem, is depressed.

DSL MODEM SR505N LIGHTS LIGHTS READ Power Solid Green Solid or Blinking LAN1-4 Green (Off if unused) Solid Green if WLAN WiFi enabled (Off if unused) DSL Solid Green Solid or Blinking Internet Green

Home Phone



CONGRATULATIONS! YOUR SETUP IS NOW COMPLETE.