DISTRIBUTEL

Smart RG 516

Internet Modem Set Up Guide

Setting up your High Speed Internet Service

DISTRIBUTEL

Before you begin:

> **Review contents of your install kit:**
  - A phone cable to connect to the network
  - An ethernet cable to connect your device
  - DSL 516 modem and power cord

> **Read through instructions**
  You can find additional self-help resources at distributel.ca/support.

  If you have a traditional home phone (e.g. Bell) you will need to use a line filter and splitter. You will find instructions for how to do this at distributel.ca/support

Part 1: Connecting the modem

1 Connect one end of the phone cable to the 'DSL' port on your modem, then connect the other end of the cable to a nearby telephone wall outlet.

2 Attach the power cord to the 'Power' port on your modem, then plug the cord into a nearby electrical wall outlet.

3 Turn the modem on, and wait until these lights are on: 'Power', 'DSL', 'Internet', 'WPS', 'USB' as well as '2.4 GHz' and '5 GHz'.

This can take about 5 minutes.

To connect your devices see instructions on the reverse side of this guide.

Setting up your High Speed Internet Service

Part 2: Connecting your devices

For information on our products and services, visit **distributel.ca**

Contact our Customer Support team at **1-877-810-2877**

Option A: Wired Connection

For fastest and most reliable speeds.

Connect one end of the ethernet cable to a 'LAN' Port on your modem and the other end to an ethernet LAN port on the device you want to connect.

SMART/RG
802.11ac VDSL2 GATEWAY
MODEL/MODÈLE: SR516ac

SR516AA048-5008142

3x2222X333XX

DSL   LAN4 LAN3 LAN2 LAN1   WAN   USB Power
                                     Reset

Option B: WiFi Connection

Connect multiple devices for use throughout your home.

1 Go to WiFi settings on device you want to connect, and search for available WiFi networks.

2 Select the WiFi network (SSID) that matches one on the bottom of your modem.

2.4 GHz SSID provides largest coverage.

5 GHz provides faster speeds within a smaller range—may not be available for all devices.

3 If asked for a password, enter the WiFi Key found on bottom of modem.

SMART/RG
802.11ac VDSL2 GATEWAY
MODÈLE/MODÈLE: SR516ac

Serial No. / N˚ de série	WiFi SSIDs
SR516AA048-5008142	2.4 GHz: SmartRG- 79de 5GHz: SmartRG- 72de-5G
MAC Adress / Adresse MAC	WiFi Key / Clé WiFi
3x2222X333XX	3x222x33x2

Engineered in the USA / Conçu aux États-Unis

You should now be ready to enjoy your Distributel High Speed Internet!

For help changing your WiFi network name or WiFi password and for additional tips visit distributel.ca/support.