



Cisco

Digital Home Phone Service

Set Up Guide

For information on our products and services,
visit distributel.ca

Contact our Customer Support team at **1-877-810-2877**



Setting up your Digital Phone Service


Before you begin:

- > **Temporarily turn off your internet modem**, and your router if you use one.
- > **Review contents of your install kit:**
 - Analog Telephone Adapter (ATA)
 - Power cord
 - Ethernet cable
- > **Read through instructions**
You can find additional self-help resources at distributel.ca/support

- 1** Be sure your phone cable is connected to your telephone or cordless phone charging station.
Connect the other end of your phone cable to the Phone 1 port on your ATA.

- 2** Connect one end of the ethernet cable to the internet port on your ATA, and the other end to an available LAN port on your internet modem.
If you use a router, connect it to a LAN port on your router instead.

- 3** Attach power cord to ATA and connect to an electrical outlet.
Turn your modem back on, and router if you use one.
After 2 minutes, Power, internet and Phone 1 lights will be on and not flashing.



After completing these 3 easy steps, you should now hear a dial-tone, and your digital phone service is ready to use!

For help setting up additional phone lines, or for tips using your phone features and setting up voice mail, visit distributel.ca/support